

<b>1</b>	<b>Function</b>	<b>PMA-13</b>
1.1	Input voltage range .....	PMA-13
1.2	Inrush current limiting .....	PMA-13
1.3	Overcurrent protection .....	PMA-13
1.4	Overvoltage protection .....	PMA-13
1.5	Output voltage adjustment .....	PMA-13
1.6	Isolation .....	PMA-13
1.7	Remote ON/OFF .....	PMA-13
<b>2</b>	<b>Series Operation and Parallel Operation</b>	<b>PMA-13</b>
<b>3</b>	<b>Temperature Measurement Point</b>	<b>PMA-14</b>
<b>4</b>	<b>Life expectancy and warranty</b>	<b>PMA-15</b>
<b>5</b>	<b>Option and Others</b>	<b>PMA-15</b>
5.1	Outline of options .....	PMA-15
5.2	Others .....	PMA-16

# 1 Function

## 1.1 Input voltage range

- Input voltage range of the power supplies is from AC85V to AC264V (please see SPECIFICATIONS for details).
- In cases that conform with safety standard, input voltage range is AC100-AC240V (50/60Hz).
- If input value doesn't fall within above range, a unit may not operate in accordance with specifications and/or start output voltage hunting or fail.  
If you need to apply a square waveform input voltage, which is commonly used in UPS and inverters, please contact us.
- When the input voltage changes suddenly, the output voltage accuracy might exceed the specification. Please contact us.

### ● PMA15F, PMA30F

- A power factor improvement circuit (active filter) is not built-in. If you use multiple units for a single system, standards for input harmonic current may not be satisfied. Please contact us for details.

## 1.2 Inrush current limiting

- An inrush current limiting circuit is built-in.
- If you need to use a switch on the input side, please select one that can withstand an input inrush current.
- Thermistor is used in the inrush current limiting circuit. When you turn the power ON/OFF repeatedly within a short period of time, please have enough intervals so that a power supply cools down before being turned on.

## 1.3 Overcurrent protection

- An overcurrent protection circuit is built-in and activated over 105% of the rated current. A unit automatically recovers when a fault condition is removed.  
Please do not use a unit in short circuit and/or under an overcurrent condition.
- Hiccup Operation Mode  
When the overcurrent protection circuit is activated and the output voltage drops to a certain extent, the output becomes hiccup so that the average current will also decrease.

## 1.4 Overvoltage protection

- An overvoltage protection circuit is built-in. If the overvoltage protection circuit is activated, shut down the input voltage, wait more than 3 minutes and turn on the AC input again to recover the output voltage. Recovery time varies depending on such factors as input voltage value at the time of the operation.

### Remarks :

Please avoid applying a voltage exceeding the rated voltage to an output terminal. Doing so may cause a power supply to malfunction or fail. If you cannot avoid doing so, for example, if you need to operate a motor, etc., please install an external diode on the output terminal to protect the unit.

## 1.5 Output voltage adjustment

- To increase an output voltage, turn a built-in potentiometer clockwise. To decrease the output voltage, turn it counterclockwise.

## 1.6 Isolation

- For a receiving inspection, such as Hi-Pot test, gradually increase (decrease) the voltage for the start (shut down). Avoid using Hi-Pot tester with the timer because it may generate voltage a few times higher than the applied voltage, at ON/OFF of a timer.

## 1.7 Remote ON/OFF

### ● PMA15F, PMA30F

- These models do not have a remote ON/OFF function.

### ● PMA60F, PMA100F

- Option -R is available to provide a remote ON/OFF function. Please see "5 Option and Others" for details.

# 2 Series Operation and Parallel Operation

- You can use a power supply in series operation. The output current in series operation should be lower than the rated current of a power supply with the lowest rated current among power supplies that are serially connected. Please make sure that no current exceeding the rated current flows into a power supply.




Fig.2.1 Examples of connecting in series operation

- Parallel operation is not possible.
- Redundancy operation is available by wiring as shown below.




Fig.2.2 Example of redundancy operation

- Even a slight difference in output voltage can affect the balance between the values of  $I_1$  and  $I_2$ . Please make sure that the value of  $I_3$  does not exceed the rated current of a power supply.

$$I_3 \leq \text{the rated current value}$$

### 3 Temperature Measurement Point

- Environment to use it and Installation environment  
When using it, it is necessary to radiate heat by the heat of the power supply.  
Table 3.1 - 3.4 shows the relation between the upper limit temperature (Point A and Point B) and load factors.  
Please consider the ventilation so that the convection which is enough for the whole power supply is provided.  
And temperature of Point A and Point B please become lower than upper limit temperature.  
The life expectancy in the upper bound temperature (Point A and Point B) is three years or more.  
Please refer to External View for the position of Point A and Point B.

**Remarks:**

- \* Please be careful of electric shock or earth leakage in case of temperature measurement, because Point A and Point B is live potential.

Table 3.1 Temperatures of Point A, Point B PMA15F-□

Mounting Method	Load factor	Max temperature	
		Point A[°C]	Point B[°C]
A	70% < $I_o \leq 100\%$	72	75
	20% < $I_o \leq 70\%$	75	77
	$I_o \leq 20\%$	77	77
B	70% < $I_o \leq 100\%$	62	62
	20% < $I_o \leq 70\%$	64	66
	$I_o \leq 20\%$	66	67
C	70% < $I_o \leq 100\%$	55	62
	20% < $I_o \leq 70\%$	58	64
	$I_o \leq 20\%$	61	63

Table 3.2 Temperatures of Point A, Point B PMA30F-□

Mounting Method	Load factor	Max temperature	
		Point A[°C]	Point B[°C]
A	70% < $I_o \leq 100\%$	77	83
	20% < $I_o \leq 70\%$	79	83
	$I_o \leq 20\%$	80	84
B	70% < $I_o \leq 100\%$	72	74
	20% < $I_o \leq 70\%$	70	74
	$I_o \leq 20\%$	71	74
C	70% < $I_o \leq 100\%$	66	76
	20% < $I_o \leq 70\%$	67	75
	$I_o \leq 20\%$	68	73

Table 3.3 Temperatures of Point A, Point B PMA60F-□

Mounting Method	Load factor	Max temperature	
		Point A[°C]	Point B[°C]
A	70% < $I_o \leq 100\%$	82	76
	20% < $I_o \leq 70\%$	88	81
	$I_o \leq 20\%$	88	83
B	70% < $I_o \leq 100\%$	66	68
	20% < $I_o \leq 70\%$	75	73
	$I_o \leq 20\%$	77	75
C	70% < $I_o \leq 100\%$	64	65
	20% < $I_o \leq 70\%$	71	72
	$I_o \leq 20\%$	73	72

Table 3.4 Temperatures of Point A, Point B PMA100F-□

Mounting Method	Load factor	Max temperature	
		Point A[°C]	Point B[°C]
A	70% < $I_o \leq 100\%$	78	80
	20% < $I_o \leq 70\%$	83	82
	$I_o \leq 20\%$	84	84
B	70% < $I_o \leq 100\%$	64	73
	20% < $I_o \leq 70\%$	70	73
	$I_o \leq 20\%$	73	75
C	70% < $I_o \leq 100\%$	59	76
	20% < $I_o \leq 70\%$	65	76
	$I_o \leq 20\%$	67	74

## 4 Life expectancy and warranty

### ■ Life Expectancy.

Please see the following tables for life expectancy.

Table 4.1 Life Expectancy

Mounting Method	Annual Average of Ambient Temperatures	Load Factor	
		50%	100%
A	Ta = 30°C or less	10 years or more	10 years or more
	Ta = 40°C	10 years or more	6 years
	Ta = 50°C	5 years	3 years
B and C	Ta = 20°C or less	10 years or more	10 years or more
	Ta = 30°C	10 years or more	6 years
	Ta = 40°C	5 years	3 years

### ■ Warranty

Table 4.2 Warranty

Mounting Method	Annual Average of Ambient Temperatures	Load Factor	
		50%	100%
A	Ta = 40°C or less	5 years	5 years
	Ta = 50°C	5 years	3 years
B and C	Ta = 30°C or less	5 years	5 years
	Ta = 40°C	5 years	3 years

## 5 Option and Others

### 5.1 Outline of options

- \* Please inquire us for details of specifications and delivery timing.
- \* You can combine multiple options. Some options, however, cannot be combined with other options. Please contact us for details.

#### ● -T

- Option -T models have vertically positioned screws on a terminal block.
- Please contact us for details about appearance.




Fig.5.1 Example of option -T (PMA100F)

#### ● -T1

- Option -T1 models have horizontally positioned screws on a terminal block.
- Please contact us for details about appearance.




Fig.5.2 Example of option -T1 (PMA100F)

● -N

- Option -N models come with a cover.
- Appearance of Option -N models are different from that of standard models. Please see External View for details.
- Derating curve for Option -N models are different from that for standard models. Please see “Derating” for details.

\*Safety agency approvals will be void if the cover is attached after the unit is ex-factoryed.

● -J1

- Option -J1 models, the Input and Output connector is VH connectors (Mfr. J.S.T.).

● -R (PMA60F, PMA100F)

- You can control output ON/OFF remotely in Option -R models. To do so, connect an external DC power supply and apply a voltage to a remote ON/OFF connector, which is available as option.

Model Name	Built-in Resistor Ri [Ω]	Voltage between RC (+) and RC (-) [V]		Input Current [mA]
		Output ON	Output OFF	
PMA60F PMA100F	780	4.5 - 12.5	0 - 0.5	(20max)




Fig.5.3 Example of using a remote ON/OFF circuit

- Dedicated harnesses are available for your purchase. Please see Optional Parts for details.

\*1 If the output of an external power supply is within the range of 4.5 - 12.5V, you do not need a current limiting resistor R. If the output exceeds 12.5V, however, please connect the current limiting resistor R.

To calculate a current limiting resistance value, please use the following equation.

$$R[\Omega] = \frac{V_{cc} - (1.1 + R_i \times 0.005)}{0.005}$$

\*Please wire carefully. If you wire wrongly, the internal components of a unit may be damaged.

■Remote ON/OFF circuits (RC+ and RC-) are isolated from input, output and FG.

5.2 Others

■While turning on the electricity, and for a while after turning off, please don't touch the inside of a power supply because there are some hot parts in that.

● PMA15F, PMA30F

■When a mass capacitor is connected with the output terminal (load side), the output might become the stop or an unstable operation. Please contact us for details when you connect the capacitor.